





# Degreaser P-4419

## **PROPERTIES**

Degreaser Plus P-4419 is a liquid suitable for removing greasy stains, dust and dirt from all types of mesh. It will also wet the surface of the mesh improving the coating of the emulsion and reducing pinholes. Degreaser should be used prior to the stencil making process. New screens should be treated with Screenprep before degreasing.

## **INSTRUCTIONS FOR USE**

1. Soak the screen mesh with water.

2. Use a soft brush to apply some of the Degreaser to both sides of the screen. With a circular motion, rub into the mesh and ensure the entire screen area is treated.

3. Leave for a few minutes.

4. Use a strong water jet or high-pressure water gun to remove the Degreaser.

5. Dry the screen thoroughly before further use.

## **STORAGE**

Degreaser should be kept in the cool location - not below 0oC/32oF or over 35oC/95oF and in a sealed container. Degreaser can be stored for up to 24 months.

## SAFETY AND HANDLING

Degreaser should be used with care. Wear suitable PPE, for example, appropriate gloves and safety glasses.

## Degreaser

- Is free from any toxic, carcinogenic, mutagenic and reprotoxic chemicals.
- Does not have a flashpoint and is, therefore, exempt from the Highly Flammable Liquid Regulations.

## **ENVIRONMENTAL INFORMATION**

**Degreaser:** 

- Does not contain heavy metals.
- Is formulated free from ozone depleting chemicals as described in the Montreal Convention.
- Is biodegradable as determined by the OECD 301D Closed Bottle Test.
- Does not have any volatile solvents and is therefore less harmful to the environment when compared with solvent-based products.

## **TECHNICAL SERVICE AND INFORMATION**

For further information or other relevant data, please do not hesitate to contact Sabinecolors has a team of well-trained personnel who are ready to give help and advice regarding product information and application.